
Hill Billy Spare Parts: *Information—The Hill Billy Battery*

Your new Hill Billy battery will give excellent service on your Hill Billy. However it is very important to look after it properly so please note this information carefully.

IMPORTANT—please READ this document BEFORE USING your new battery
Please read these instructions carefully. Return faulty parts that are under warranty.

Activating a new battery...

1. This battery can require up to 6 uses before it reaches optimum performance. During this initial period, although the battery will power your Hill Billy normally on the golf course, it may cause the battery charger to behave differently.
2. When recharging after the first use, if the light on your charger should remain red for more than 10 hours, turn it off and disconnect the battery. The battery will be fully charged. There is no need to reconnect it to the charger before it's used again.
3. After a maximum of 6 uses the charger will function normally again; with the light switching automatically to green during the charging cycle. At this point you should revert to leaving the battery on charge permanently between uses.

To maximise battery life...

1. Always return the battery to the charger as soon as possible after use (certainly within 24 hours). Repeated failure to do this will dramatically shorten the battery's life. If you have two batteries to charge, connect them in the order in which they were used.
2. Do not remove the battery from the charger for at least 10 hours.
3. If possible, leave the battery connected to the charger, with the main breaker switched on, all the time it is not being used. This will not waste electricity.
4. Do not use the same battery for more than 18 holes before fully recharging. If less than 18 holes were played the battery must still be recharged for at least 10 hours.
5. If the battery is going to be unused for an extended period it can still be left on charge. If this is not possible, before disconnecting it you must ensure it is fully charged (at least 10 hours) and it should then be stored in a cool place.
6. **Always** set your Hill Billy rolling **before** turning on the power.
7. Do not use a golf bag heavier than necessary. Battery life reduces as the weight of your gear increases. We recommend a sensible maximum for the golf bag and it's contents is 14 kgs.

Charger Operation...

1. When the red light shows, the charger is in "fast charge" mode. When the green light shows it is in "low power mode".
2. The battery should not be used as soon as the green light appears. At this stage it is only 90-95% charged. The battery will only reach 100% charge after being connected for at least 10 hours.
3. When first connecting the battery, **always** check that the red light is showing. This will confirm the battery is properly connected and that the charger is working normally.
4. Never leave the battery connected to the charger with the main breaker or power switched off or disconnected.
5. To ensure correct operation, only use your charger with the indicator lights facing upwards.
6. Please refer to your Hill Billy owners manual for further information about using your battery.