

---

**Hill Billy Spare Parts: *Fitting Instructions— Replacement Frame Locking Catch***

---

Please read these instructions carefully. Return faulty parts that are under warranty.

---

**Fitting the replacement frame locking catch**

1. Using a flat bladed screwdriver, pry off one of the dome shaped fasteners on the side of the old catch.
2. Withdraw the pivot pin from the side which has the other fastener still attached.
3. Unhook the catch return spring from the trolley frame and remove it complete with the old catch.
4. Taking the new frame catch and spring, hook the spring into the hole in the frame. Align the two mounting holes in the new catch with those in the frame and insert the new pivot pin, which already has one domed fastener attached.
5. Position the trolley so that the domed fastener on the pivot pin is against a solid surface and using firm pressure, push the other fastener onto the end of the pin.

